


## ELECTRIC TOOL PARTS LIST

■ AIR COMPRESSOR  
Model EC89

2009 • 09 • 10  
(E1)



## Parts List

EC89

Item #	Code #	DESCRIPTION	NO USED	Remarks
1	881472	SCREW (10 pc.)	1	
2	881554	INTAKE FILTER HOUSING	1	
3	881553	FILTER ELEMENT	1	
4	881453	FILTER PLATE	1	
5	887053	JOINT	1	
6	887054	SET OF GASKET	1	
7	887055	CYLINDER	1	
8	881460	PISTON RINGS	1	
9	881462	PISTON PIN	1	
10	881463	RETAINING RING (5PC.)	2	
11	881561	CONNECTING ROD	1	
12	881551	SCREW (5PC.)	4	
13	887057	HEAD (INCLUDES ITEM 23)	1	
14	885551	VALVE PLATE KIT	1	
15	160582	RUBBER, NON-RETURN VALVE	1	
16	881489	NUT (10PC.)	2	
17	881461	PISTON	1	
18	887059	COUNTER WEIGHT	1	
19	160584	HOUSING	1	
20	881485	WASHER (10PC.)	1	
21	885557	NUT	1	
22	881469	DIPSTICK	1	
23	887060	START VALVE	1	
24	881566	STUD BOLT (3PC.)	1	
25	887061	CAPACITOR	1	
26			1	
27	160587	TANK (INCLUDES ITEMS 51& 53)	1	
28	884444	SCREW (10PC.)	1	
29	884450	DRAIN CAP	1	
30	881666	SCREW (10PC.)	3	
31	887062	CARTER COVER	1	
32	887063	GASKET, CARTER COVER	1	
33	887064	CRANK SHAFT WITH ROTOR	1	
34	6204DD	BALL BEARING, FRONT	1	
35	885457	OIL SEAL RING, 21 X 47 X 7	1	
36	887065	CRANK CASE	1	
37	881589	NUT (10PC.)	4	
38	887066	MOTOR STATOR	1	
39	6203ZZ	BALL BEARING, REAR	1	
40	887067	REAR COVER	1	
41	887068	FAN	1	
42	887069	TENSION ROD	2	
43	881479	SCREW (5PC.)	4	
44	882610	DISCHARGE TAP	2	
45	160571	COMPRESSION NUT (3PC.)	1	
46	160570	FERRULE (5PC.)	1	
47	881571	SCREW (5PC.)	4	
48	881572	WASHER (10PC.)	4	
49	881583	RUBBER WASHER (5PC.)	4	
50	881570	BASE PLATE	1	



